

Smart water meter installation instructions

Flow meter can be installed on any cold water pipe with flow rate of up to 35 litres per minute. E.g. washing machine, geyser supply, toilet, or house supply. Register at <https://app.bridgiot.co.za>

In the box:

1 x Included: electronic controller with a flow meter and 230V power plug

What you need:

A wall plug less than 4 meter away from the water connection.

If you want to connect to a pipe, you need conex (compression) couplings. For example, to connect to a 22mm pipe, you will need 2 x 22mm conex couplings to $\frac{3}{4}$ " female couplings (the flow meter has male $\frac{3}{4}$ " thread).

If you want to connect to your washing machine you need an extra supply pipe.

Plumbing: Smart water meter installation:

Check the arrow on flow meter for direction of flow of flow meter – flow must be in the same direction as arrow.

The black sensing part can be removed from the flow meter for easy installation.

Install meter horizontally.

The box can easily be mounted to the wall through mounting holes that are under the lid, next to the lid's mounting holes.

The green LED indicates connectivity:

3 flashes = connecting, 1 flash = connected.

The red LED will flash when water flows.

